



NEWWOOD SOLUTIONS Ltd

Derby Office: 15 Kings Croft, Allestree, Derby, DE22 2FP.
Tel +44 (0)1332 721326

Reading Office: 13 Highfield Road, Tilehurst, Reading RG31 6YR.
Tel +44 (0) 118 9012298

Email: sales@newwoodsolutions.co.uk

Web: www.newwoodsolutions.co.uk

8904 8-Channel RS-232 DIN-Rail Mounted Connector Board

USERS MANUAL

Document Nos.: 8904/UTM/G/x/1.1

Date: 30/12/2019

Author: AB/MRN

Revision History

The following table shows the revision history for this document.

| Date | Version | Revision |
|----------|---------|--|
| 05/10/15 | 1.0 | Use manual issue |
| 30/12/19 | 1.1 | Change from Hytec to Newwood Solutions for contact details |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

CRITICAL APPLICATIONS DISCLAIMER

THIS PRODUCT FROM NEWWOOD SOLUTIONS LTD USES COMPONENTS THAT ARE NOT DESIGNED OR INTENDED TO BE FAIL-SAFE, OR FOR USE IN ANY APPLICATION REQUIRING FAIL-SAFE PERFORMANCE, SUCH AS IN LIFE-SUPPORT OR SAFETY DEVICES OR SYSTEMS, CLASS III MEDICAL DEVICES, NUCLEAR FACILITIES, APPLICATIONS RELATED TO THE DEPLOYMENT OF AIRBAGS, OR ANY OTHER APPLICATIONS THAT COULD LEAD TO DEATH, PERSONAL INJURY OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE (INDIVIDUALLY AND COLLECTIVELY, "CRITICAL APPLICATIONS").

FURTHERMORE, SOME COMPONENTS USED IN THIS NEWWOOD SOLUTIONS LTD PRODUCTS ARE NOT DESIGNED OR INTENDED FOR USE IN ANY APPLICATIONS THAT AFFECT CONTROL OF A VEHICLE OR AIRCRAFT, UNLESS THERE IS A FAIL-SAFE OR REDUNDANCY FEATURE AND A WARNING SIGNAL UPON FAILURE TO THE OPERATOR.

THE CUSTOMER ASSUMES THE SOLE RISK AND LIABILITY OF ANY USE OF NEWWOOD SOLUTIONS LTD PRODUCT IN CRITICAL APPLICATIONS.

CONTENTS

| | |
|---|---|
| 1. INTRODUCTION | 4 |
| 2. PRODUCT SPECIFICATIONS | 4 |
| 3. BOARD DESCRIPTION..... | 4 |
| 4. OPERATION..... | 4 |
| 5. 8904 SERIAL CONNECTION DIN-RAIL BOARD PIN-OUT..... | 5 |

1. INTRODUCTION

The Newwood Solutions 8904 is a DIN-Rail mounted board which allows connection to the IP-SI-8515 and IP-SI-8516 serial I/O cards using 9-way D-type connectors. It connects to the IP cards via a straight-through transition board type 8304 using a 50-way SCSI cable.

- 8 off 9-way D-type sockets connect to serial peripheral equipment.
- SCSI socket connects to transition board
- Supports one serial IP card. (Four units can be used for four serial IP cards mounted on one 8002 Carrier Board.)
- Each 9-way socket carries Tx/Rx/RTS/CTS/GND connections.
- Common mode bias resistors for differential inputs
- CTS lines brought to circuit pads
- +12V brought to 8 off circuit pads via optional pull-up resistor.
- Transient voltage protection

2. PRODUCT SPECIFICATIONS

| | |
|-----------------------|---|
| Size: | DIN-rail mounted module approx 150x75x45mm |
| Operating temp: | 0 to 45 deg C ambient |
| Power Requirements: | +12V connection to IP card for pull-up resistors (optional use) |
| Number of channels: | 8 |
| Number of signals: | 4 (Tx/Rx/RTS/CTS) plus 2 Gnd connections |
| Connectors: | SCSI 50-way socket for connection to transition board 8 off 9-way D-type sockets with female retainers |
| Transient protection: | 18V clamp rising to 40V max @ 10A |

3. BOARD DESCRIPTION

The board is primarily intended to route 8 serial channels from the IP-SI-8515 (or 8516) card to 8 off 9-way D-type sockets. The IP card would normally be plugged onto one site of a carrier board (e.g.8002) and the signals routed to the rear of a VME64X crate using a straight-through transition board (e.g. 8304). One 8904 is required per 8515 card. Four are required if a full complement of 8515s are sited on an 8002 Carrier Board. Connections to the 8304 Transition Board, (which routes all four sets to 4off SCSI sockets), are made using 50-way SCSI cables. Each one of 8 sets of signals comprising Tx, Rx, /RTS, /CTS and Gnd is routed through to Sockets 1-8 from the 50-way SCSI socket.

The +12V fused output is brought through from the IP-SI-8515 card to 8 pull-up resistor located in RN1. These are made available for patching on pads TP1-TP8.

/CTS0- /CTS7 are connected to pads TP17-TP24.

The Aux1-Aux8 lines, (TTL level inputs on the 8515), are connected to pads TP9-TP16 for optional use.

4. OPERATION

4.1 Connection to Transition Board

Connect the unit to the SCSI socket on the transition board for the relevant carrier board site (e.g. lowest of the four connectors for an 8515 plugged into site A)

4.2 Connection to RS-232 Equipment

For each 9-way equipment connection use twisted pair cable to connect Rx of the receiving equipment to pin3 and its Ground return to pin5. Connect Tx of the receiving equipment to pin2 and its Ground the return to pin5 or alternatively to pin1.

If RTS/CTS control is to be used connect these using twisted pairs in a similar fashion

4.3 Connection to RS-485 Equipment

Use a twisted pair to connect Rx- and Rx+ of the receiving equipment to pin3 (Tx-) and pin2 (Tx+). If full duplex is used connect Tx- and Tx+ of the receiving equipment to pin7 (Rx-) and pin8 (Rx+). Connect the Ground to pins 1 or 5.

5.8904 Serial Connection DIN-Rail Board Pin-out

| SCSI 50-way | 9-way Socket | 8515 RS-232 | 8516 RS-485 | Comment |
|-------------|--------------|-------------|-------------|----------------|
| 26 | SK1-1 & 5 | GND | GND | |
| 1 | SK1-3 | Tx0 | Tx0- | For RS-485 in |
| 27 | SK1-2 | Rx0 | Tx0+ | HD mode Tx |
| 2 | SK1-7 | /RTS0 | Rx0- | pins double as |
| 28 | SK1-8 | /CTS0 | Rx0+ | Rx pins |
| 3 | SK2-1 & 5 | GND | GND | |
| 29 | SK2-3 | Tx1 | Tx1- | |
| 4 | SK2-2 | Rx1 | Tx1+ | |
| 30 | SK2-7 | /RTS1 | Rx1- | |
| 5 | SK2-8 | /CTS1 | Rx1+ | |
| 31 | SK3-1 & 5 | GND | GND | |
| 6 | SK3-3 | Tx2 | Tx2- | |
| 32 | SK3-2 | Rx2 | Tx2+ | |
| 7 | SK3-7 | /RTS2 | Rx2- | |
| 33 | SK3-8 | /CTS2 | Rx2+ | |
| 8 | SK4-1 & 5 | GND | GND | |
| 34 | SK4-3 | Tx3 | Tx3- | |
| 9 | SK4-2 | Rx3 | Tx3+ | |
| 35 | SK4-7 | /RTS3 | Rx3- | |
| 10 | SK4-8 | /CTS3 | Rx3+ | |
| 36 | SK5-1 & 5 | GND | GND | |
| 11 | SK5-3 | Tx4 | Tx4- | |
| 37 | SK5-2 | Rx4 | Tx4+ | |
| 12 | SK5-7 | /RTS4 | Rx4- | |
| 38 | SK5-8 | /CTS4 | Rx4+ | |
| 13 | SK6-1 & 5 | GND | GND | |
| 39 | SK6-3 | Tx5 | Tx5- | |
| 14 | SK6-2 | Rx5 | Tx5+ | |
| 40 | SK6-7 | /RTS5 | Rx5- | |
| 15 | SK6-8 | /CTS5 | Rx5+ | |
| 41 | SK7-1 & 5 | GND | GND | |
| 16 | SK7-3 | Tx6 | Tx6- | |
| 42 | SK7-2 | Rx6 | Tx6+ | |
| 17 | SK7-7 | /RTS6 | Rx6- | |
| 43 | SK7-8 | /CTS6 | Rx6+ | |
| 18 | SK8-1 & 5 | GND | GND | |
| 44 | SK8-3 | Tx7 | Tx7- | |
| 19 | SK8-2 | Rx7 | Tx7+ | |
| 45 | SK8-7 | /RTS7 | Rx7- | |
| 20 | SK8-8 | /CTS7 | Rx7+ | |
| 46 | | GND | GND | |
| 21 | | +12V | +5V | TP1-TP8 * |
| 47 | | TTL I/P1 | N/C | TP9 |
| 22 | | TTL I/P2 | N/C | TP10 |
| 48 | | TTL I/P3 | N/C | TP11 |
| 23 | | TTL I/P4 | N/C | TP12 |
| 49 | | TTL I/P5 | N/C | TP13 |
| 24 | | TTL I/P6 | N/C | TP14 |
| 50 | | TTL I/P7 | N/C | TP15 |
| 25 | | TTL I/P8 | N/C | TP16 |